


SR 570

EN

Spare parts / Accessories



| No.. | Description | Ordering No. |
|-------------|---|---------------------|
| 1. | Breathing hose | R06-0635 |
| 2. | Gasket for hose | R01-3011 |
| 3. | Exhalation membrane | R06-0614 |
| 4. | Head harness | R06-0601 |
| 5. | Head harness seal | R06-0610 |
| 6. | Sweatband | R06-0602 |
| 7. | Face seal | R06-0603 |
| 8. | Visor set, PC | R06-0616 |
| 9. | Peel-off 10 pcs | T06-0601 |
| | Peel-off 100 pcs | T06-0608 |
| 10. | Clips for peel off | T06-0607 |
| 11. | Bump cap | T06-0602 |
| 12. | Neck cover <i>Note! T06-0602 is required</i> | T06-0603 |
| 13. | Cover with thread and knob | T06-0640 |
| 13a | Knob complete | R06-0821 |
| 14. | Visor 2/3 EN 5 | T06-0605 |
| | Visor 2/3 EN 3 | T06-0609 |
| | <i>Note! T06-0640 is required</i> | |
| 15. | Cleaning tissues, box of 50 | H09-0401 |
| 16. | Hose protection, PE | T06-0121 |
| 17. | Tyvek Hood SR 586 | T06-0806 |