



Vinyl cleaning glove

Article no. 4362-4365

Family Phthalates Free Vinyl Glove flocklined



Description

Blue cleaning glove made of vinyl
Phthalate free
Flocklined on the inner-side for absorption of sweat
Anatomically shaped so they counteract fatigue and load in the hands
Textured inner surface for a better grip even in wet condition
No rolled cuff
Produced for ABENA A/S DK, under ISO9001:2008

CE

CE-labelled according to EU directive 89/686/EEC

Standard

EN 420
Tested according to EN 374 & EN 388

Packaging

12 pairs per bag
12 bags per carton (144 pairs)
16 carton per pallet

Thickness and size

Palm: min. 0,45 (+/- 0,02 mm)

Size	Art. No	Int. Str.	Palm mm (+/- 5)	Length mm (+/- 5)
Small	4362	6-7	85	300
Medium	4363	7-8	95	300
Large	4364	8-9	105	300
X-Large	4365	9-10	115	300



Vinyl cleaning glove

Article no. 4362-4365

Chemical	CAS	Permeation time	Class
Acetaldehyde	75-07-0	< 1 min.	0
Acetic acid 50%	64-49-7	<85 min.	3
Acetic acid 99,7%	64-19-7	<21 min.	1
Acetic anhydride 97%	108-24-7	<13 min.	1
Acetone	67-64-1	<1 min.	0
Acetonitrile	75-05-8	<1 min.	0
n-Amyl acetate	628-63-7	<1 min.	0
Benzaldehyde	100-52-7	<1 min.	0
Benzene	71-43-2	<1 min.	0
1-Butanol	71-36-3	<45 min.	2
2-Butanol	78-92-2	<48 min.	2
Butyl acetate	123-86-4	<1 min.	0
Butylamine	109-73-9	<4 min.	0
Carbon tetrachloride	56-23-5	<6 min.	0
Chlorobenzene	108-90-7	<1 min.	0
Chloroform	67-66-3	<1 min.	0
Citric acid 25%	77-92-9	>480 min.	6
Cumene	98-82-8	<1 min.	0
Cyclohexane	110-82-7	<20 min.	1
Cyclohexanol	108-93-0	<230 min.	4
Cyclohexanone	108-94-1	<13 min.	1
Diacetone Alcohol	123-42-2	<24 min.	1
Diethylamine	109-89-7	<1 min.	0
Diethyl ketone	96-22-0	<1 min.	0
N, N-Dmethylformamid	68-12-2	<1 min.	0
1,4 – Dioxane	123-91-1	<1 min.	0
EDTA-4Na 40%	60-00-4	>480 min.	6
Ethanol	64-17-5	<27 min.	1
Ethyl acetate	141-78-6	<1 min.	0
Ethylene chloride	107-06-2	<1 min.	0
Ethylene Diamine	107-15-3	<5 min.	0
Ethyl ether	60-29-7	<1 min.	0
Ethylene Glycol Monobuthyl Ether	111-76-2	<11 min.	1
Ethylene Glycol Monoethyl Ether	110-80-5	<13 min.	1
Ethylene Glycol Monoethyl Ether Acetate	111-15-9	<10 min.	0
Formic acid 99%	64-18-6	<5 min.	0
Glutaraldehyde 2,5%	111-30-8	>480 min.	6
Glycolic acid 70%	79-14-1	>480 min.	6
n-Heptane	142-82-5	<17 min.	1
Hexane	10-82-5	<10 min.	1
Hydro chloric acid 10%	7647-01-0	>480 min.	6



Vinyl cleaning glove

Article no. 4362-4365

Hydro chloric acid 10%	7647-01-0	>480 min.	6
Iso butylAlcohol	78-83-1	<39 min.	2
Iso octane	540-84-1	<88 min.	3
Iso pentyl acetate	123-92-2	<10 min.	0
Isopropanol	67-63-0	<40 min.	2
Kerosene	8008-20-6	>480 min.	6
Lactic acid 85%	50-21-5	>480 min.	6
D-Limonene	5989-27-5	<19 min.	1
Maleic acid 40%	110-16-7	>480 min.	6
Methanol	67-56-1	<11 min.	1
Methyl acetate	79-20-9	<10 min.	0
Methylene chloride	75-09-2	<1 min	0
Methyl ethyl ketone	78-93-3	<1 min.	0
Methyl isobutyl ketone	108-10-1	<1 min.	0
Methyl isopropyl ketone	107-87-9	<1 min.	0
N-Methyl 2-pyrrolidone	872-50-4	<19 min.	1
Nitric acid 16%	7697-37-2	>480 min.	6
Nitric acid 35%	7697-37-2	>480 min.	6
Nitric acid 70%	7697-37-2	<47 min.	2
n-Octane	111-65-9	<10 min.	0
1-Octanol	111-87-5	>480 min.	6
Pentane	109-66-0	<10 min.	0
1-Pentanol	71-41-0	<63 min.	3
Perchloroethylene	127-18-4	<1 min	0
Petroleum ether	8030-30-6	<16 min.	1
Phosphoric acid 85%	7664-38-2	>480 min.	6
Potassium hydroxide 50%	1310-58-3	>480 min.	6
1-Propanol	71-23-8	<36 min.	2
n-Proryl acetate	109-60-4	<1 min.	0
SDS 25%	151-21-3	>480 min.	6
Sodium hypochlorite 10%	7681-52-9	>480 min.	6
Sodium hydroxide 5%	1310-73-2	>480 min.	6
Sodium hydroxide 40%	1310-73-2	>480 min.	6
Sodium hydroxide 50%	1310-73-2	>480 min.	6
Styrene monomer	100-42-5	<1 min.	0
Sulfuric acid 50%	7664-93-9	>480 min	6
Sulfuric acid 96%	7664-93-9	<225 min.	4
Tetrahydrofurane	109-99-9	<1 min.	0
Toluene	108-88-3	<1 min.	0
Trichlorethylene	79-01-6	<1 min.	0
Unleaded petrol	-	<4 min.	0
Xylene	1330-20-7	<1 min.	0

Tests are preformed on laboratories, the permeation time are therefore not 100% comparable with real working procedures.